

USER MANUAL

KL-6500 (-i) CENTRAL COMPUTER



KL-6500

Shut down power before opening the central computer!

The central computer contains exposed live parts!

Only to be opened by authorized personnel!



WARNING

Although utmost care has been given to the quality of this equipment during the design and manufacturing stages, technical malfunctions can never be ruled out. ***The user should ensure that an adequate alarm system and/or emergency provisions is/are in place to prevent any technical failure of the equipment and peripheral facilities leading to danger to people, animals or property.***

IN THE EVENT OF AN EMERGENCY, NOTE DOWN THE FOLLOWING

- **Installer settings.**
- **Circumstances in which the emergency occurred**
- **Possible causes**
- **Software version number**



If you have any questions, please contact our Customer Service Department. Be sure to have all necessary data at hand. To ensure a speedy solution to the malfunction, and to avoid any misunderstandings, it is advisable to note down the cause and the circumstances in which the malfunction occurred before contacting us.

No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of Stienen BE (www.StienenBE.com)

Stienen BE accepts no liability for the contents of this manual and explicitly waives all implicit guarantees of marketability or fitness for a certain use. Stienen BE also reserves the right to improve or change this manual without being under the obligation to inform any person or organisation of any such improvement or change.

Stienen BE cannot be held liable for any damage, loss or injury resulting from improper use or from use not in accordance with the instructions in this manual.

OPERATION	4
Changing languages	4
Login	4
Control keys	4
Confirm change	5
Led bar	5
Room bar	5
I/O terminal numbers	5
 MAIN MENU	6
Overview screen	6
 MANAGEMENT	8
 Room	8
 Central	8
 ROOM CONTROLLER (KLD-100)	9
 Room ventilation	9
 Inlet flap	11
 Room heating	12
 Inlet heating	14
 Floor heating	15
 Cooling	17
 Alarm	18
 CENTRAL CONTROLLERS (KLC-100)	21
 Central ventilation	21
 Central heating	22
 Central inlet flap	23
 Pressure measurement	24
 ALARMS	25
 Alarm status	25
 Alarm history	26
 Communication alarm	26
 SYSTEM	27
 System	27
 Device	27
 Date and time	28
 Remote control	28
MAINTENANCE AND INSPECTION	30

OPERATION

CHANGING LANGUAGES

Languages present: ENG NLD DEU FRA RUS POL HUN SPA CES TUR ZHO JAP
← Back Next →

    : select next language (see also " System", page 27).

    : select previous language.

LOGIN

Tap  : open login screen.

Tap  : open numeric keypad.

Enter the access code and touch .

CONTROL KEYS



 : return to the overview screen (HOME).

  : select next/previous screen.

  : select input position.

 : select an option.

  : next/previous screen.

  : scroll down/up (scroll bar on the right).

 If this symbol is lit, tap it to display one of the following virtual keyboards.

Set numeric value:

 and  : change the symbol of a value.

Alphanumeric:


           


           

 and  : choose other characters.

 : toggle between lowercase and uppercase letters.

 : switch to digits and alternative characters.

  : decrease/increase value.

  : select an option from an option box.

 : undo an option/selection in *edit mode*.

 : confirm an option/selection in *edit mode*.

  : add a breakpoint to or remove it from a list (curve, timer).

  : if a setting is followed by the “Link”  symbol, use this link to access another screen. The upper right-hand corner of the “follow-up screen” will then show the “Link back”  symbol.

CONFIRM CHANGE



Some important settings can only be changed if the change has been confirmed. A pop-up window will show to confirm your change.

LED BAR



Blue permanently lit:

device not in use



Green permanently lit:

no alarm

Yellow permanently lit:

alarm, alarm delay time has not elapsed

Red permanently lit:
flashing at a regular frequency:
flashing irregularly:

alarm
main alarm switched off.
alarm switched off temporarily.


ROOM BAR

							
 Room status:	 Room in operation, no alarm.	 Alarm, alarm delay active.	 Alarm, alarm relay in.	 Room out of operation.			
 Room heating status	 Heating off	 Heating on					
 Room address	 Room name	 Room temperature					
 Room ventilation	 Number of animals in the room	 Growth curve day number					


I/O TERMINAL NUMBERS

I/O type	Letter	Serial number	Explanation
0-10V output	A	1-99	Analogue output with a range of 0-10V or 10-0V.
Relay output	B	1-99	Relay contact output (this does not include: alarm relay, digital outputs etc.)
Temperature sensor	K	1-99	This includes all types of temperature sensor fitted with 10K NTC resistors (N10B, BV10B etc.)
0-10V inputs	L	1-99	Analogue input with a measuring range of 0-10V. To connect components such as measuring sensors (RH, pressure, CO ₂ etc.)
Digital input	M	1-99	This includes measuring fans, counter contacts etc.

MAIN MENU





OVERVIEW SCREEN





Tap the "Screen" or tap the "Home"  key: this brings up the main menu.

ADD MENU ITEM TO FAVOURITES BAR



- Select the screen that should be added to the favourites bar.
- Touch the menu item icon until the “add” window is displayed.
- Tap ✓ (OK) to add the menu item to the favourites bar.

REMOVE MENU ITEM FROM FAVOURITES BAR



- Touch the icon of the menu item that you would like to remove until you see the “delete” window.
- Tap ✓ (OK) in order to remove the menu item from your favourites bar.


ROOM



Animal data:

- Curve day number.
- Current number of animals in the house

MIN./MAX. TABLE




Min./Max. house temperature table.

Min./Max. outside temperature table.

Reset min./max. value today (of all tables).

HOURS COUNTER




Room heating operating hours*.

Inlet heating operating hours*.

Floor heating operating hours*.

CENTRAL

HEATING




Min./Max. outside temperature table.

Central heating operating hours*.

Reset min./max. value today (of all tables).

* The operating hours can be cleared by setting the slider behind "Clear operating hours" to "1".

ROOM VENTILATION



- 100%
- 10%
- 20.0 °C
- 4.0 °C
- 18.1 °C
- 10 %
- 10 %
- 1.1 °C
- 1,100 m³/h

Maximum ventilation (with the room temperature + bandwidth settings chosen)

Minimum ventilation (with the room temperature setting chosen)

Room temperature setting

Bandwidth

Current room temperature

Calculated ventilation

Current ventilation

Current outside temperature


Current ventilation capacity

ROOM CURVE (TEMPERATURE, MINIMUM VENTILATION, MAXIMUM VENTILATION)




Curve : 001 (Room 1)

2.1.2.1



Point



Room temperature curve "On"

Room temperature curve "Off"

Breakpoint number

Breakpoint day number (the value under is the current day number)

Room temperature for the preset day number.

Minimum ventilation for the preset day number.


Maximum ventilation for the preset day number.

ROOM ALARM (TEMPERATURE, VENTILATION)



Alarm : 001 (Room 1)

2.1.3.1



			Room temperature alarm "On"
			Room temperature alarm "Off"
	20.3 °C		Current room temperature alarm
	-05.0 °C	15.0 °C	Minimum room temperature alarm limit
	05.0 °C	25.0 °C	Maximum room temperature alarm limit
	35.0 °C		Absolute room temperature alarm limit

			Ventilation alarm "On"
			Ventilation alarm "Off"
	14 %		Minimum ventilation limit
	34 %		Maximum ventilation limit
	12 %	24 %	Calculated and measured ventilation


The ventilation alarm only shows if a measuring fan has been installed.

INLET FLAP



Settings : 001 (Room 1)

2.2.1.1



	24 %	Current ventilation
	24 %	Current valve position


The flap controls on the basis of ventilation. Normally, the opening of the flap is directly proportional to the flap position as a %. The air displacement caused by this flap, however, is not directly proportional to the flap position. The characteristic can be used to obtain a better flap position/air displacement ratio.

ROOM HEATING



Settings : 001 (Room 1)

2.3.1.1



°C 19.0 °C

 19.0 °C

18.6 °C

19.2 °C 0 %

18.6 °C 20 %


- Room heating temperature setting (temperature difference relative to room temperature setting, see screen 2.1.1.x page 9).
- Calculated room heating temperature.
- Calculated room heating temperature from curve.
- Current room temperature.
- The room heating status is On ("On/Off heating").
- Current room temperature.
- Room heating status (heating is: "Off").
- Current heating capacity of room heating ("controlled heating")
- Current room temperature.
- Room heating status (heating is: "On").
- Current heating capacity of room heating ("controlled heating")

ROOM HEATING CURVE



Curve : 001 (Room 1)

2.3.2.1



Room heating curve "On"



Room heating curve "Off"

Point

Breakpoint number



(1)

Breakpoint day number (the value under  is the current day number)



Room heating temperature for the preset day number.


The day numbers can only be set in the "Room curve".

INLET HEATING



Settings : 001 (Room 1)

2.4.1.1




- 12.0 °C 12.0 °C • Inlet temperature setting
 • Calculated inlet temperature
- 11.3 °C • Inlet temperature setting from curve
- 9.9 °C • Current inlet temperature
 • Inlet heating status ("On/Off heating")
- 15.0 °C 0 % • Current inlet temperature
 • Inlet heating status (heating is: "Off")
 • Current heating capacity ("controlled heating")
- 9.9 °C 62 % • Current inlet temperature
 • Inlet heating status (heating is: "On")
 • Current heating capacity ("controlled heating")

INLET HEATING CURVE



Curve : 001 (Room 1)

2.4.2.1



Inlet temperature curve "On"



Inlet temperature curve "Off"

Point

Breakpoint number



(20)

Breakpoint day number (the value under  is the current day number)



°C

Inlet temperature for the preset day number.

The day numbers can only be set in the "Room curve".

INLET HEATING ALARM



Alarm : 001 (Room 1)

2.4.3.1



9.9 °C



-05.0 °C

5.9 °C



05.0 °C

15.9 °C



35.0 °C



Inlet temperature alarm "On"



Inlet temperature alarm "Off"



9.9 °C

Current inlet temperature alarm



-05.0 °C

5.9 °C

Minimum inlet temperature alarm limit



05.0 °C

15.9 °C

Maximum inlet temperature alarm limit



35.0 °C

Absolute inlet temperature alarm limit

FLOOR HEATING



Settings : 001 (Room 1)

2.5.1.1



100%

0%

-5.0

40.0

38%



40.0 °C



38.1 °C



38 %



40.0 °C

40.0 °C

- Floor temperature setting
- Calculated floor temperature




40.0 °C

- Floor temperature setting from curve

	38.1 °C		
	38.1 °C		0 %
	38.1 °C		38 %

- Current floor temperature
- Floor heating status (“On/Off heating”)
- Current floor temperature
- Floor heating status (heating is: “Off”)
- Current heating capacity (“controlled heating”)
- Current floor temperature
- Floor heating status (heating is: “On”)
- Current heating capacity (“controlled heating”)

FLOOR HEATING CURVE



Point

(20)

°C

Breakpoint number

Breakpoint day number (the value under is the current day number)

Room temperature for the preset day number.

The day numbers can only be set in the “Room curve”.

FLOOR HEATING ALARM



Alarm : 001 (Room 1) 2.5.3.1

		38.1 °C	
	<input type="text" value="-10.0"/>	°C	30.0 °C
	<input type="text" value="10.0"/>	°C	50.0 °C

		Floor heating alarm “On”
		Floor heating alarm “Off”

	38.1 °C	Current floor heating temperature
	-10.0 °C	30.0 °C Minimum floor heating alarm limit
	10.0 °C	50.0 °C Maximum floor heating alarm limit

COOLING



Settings : 001 (Room 1) 2.6.1.1

04.0 °C

24.0 °C

25.4 °C

			Cooling "On"
			Cooling "Off"
	<div style="border: 1px solid gray; padding: 2px;">04.0 °C</div>	24.0 °C	<ul style="list-style-type: none"> Cooling temperature setting Calculated cooling temperature
		25.0 °C	<ul style="list-style-type: none"> Cooling temperature setting from curve
	<div style="border: 1px solid gray; padding: 2px;">25.4 °C</div>		<ul style="list-style-type: none"> Current cooling temperature Cooling status "On"
	<div style="border: 1px solid gray; padding: 2px;">20.3 °C</div>		<ul style="list-style-type: none"> Current cooling temperature Cooling status "Off"

COOLING CURVE



Curve : 001 (Room 1) 2.6.2.1

Point	 (20)	 °C
1	004	04.0
2	028	04.0
3	077	04.0
4	140	04.0



Cooling curve "On"



Cooling curve "Off"

Point

Breakpoint number



Breakpoint day number (the value under is the current day number)



Cooling temperature for the preset day number.

The day numbers can only be set in the "Room curve".

ALARM



Main alarm : 001 (Room 1) 2.7.1.1

Main alarm on/off

Alarm temporarily off

Siren test

MAIN ALARM

If the main alarm is off, the LED bar will flash red, at a regular frequency. No alarms will be generated then. See also LED bar page 5.

ALARM TEMPORARILY OFF

Temporarily disabling the main alarm (siren). Hardware alarms cannot be switched off temporarily. The main alarm is switched off for 30 minutes (the LED bar will flash irregularly). The main alarm is switched on automatically again after 30 minutes. The alarm relay will de-energize again, causing an alarm, if the cause of the alarm has not been removed.

SIREN TEST

Test the alarm relay (siren). The alarm relay (siren) is switched on for 120 seconds.

ALARM STATUS

Alarm on			Alarm off (alarm relay is NOT switched on)			
No alarm	Alarm in the making	Alarm (alarm relay in)	No alarm	Alarm in the making	Alarm	
						Device
						Room temperature
						Ventilation
						Outside temperature
						Inlet heating
						Room heating
						Central ventilation
						Central ventilation pressure control
						Central inlet flap
						Central heating
						Pressure measurement

ALARM CODES

	Module not found
	Jumper A on RTCPU is in its lower position, set jumper A to its upper position or else the changes will not be saved.
	Communication error between devices.
	Communication error with WEB-485 (FramConnect)
	No data from climate controllers
	No ventilation (measurement = 0%).
	Ventilation too low
	Ventilation too high
	No outside temperature sensor
	Temperature sensor faulty
	Pressure sensor faulty
	Temperature too low
	Temperature too high
	Pressure too low
	Pressure too high
	If no icon is linked to the alarm code, the alarm code will be shown in a red box (please contact your supplier to report this alarm situation in order to make sure that this alarm code will be displayed correctly in the future).

Note NEVER FORGET TO SWITCH AN ALARM "ON" AGAIN AFTER IT WAS SWITCHED OFF (e.g. in order to remedy a malfunction). Failing to switch the alarm back on may have adverse effects for people, animals, equipment or property.

Preferably use the *alarm temporarily off* function to remedy a malfunction.

CENTRAL VENTILATION



Settings : 003 (Central vent. 1) 3.1.1.1

0 25 50 75 100

70%

%

+/- -5 % 50 s

\bar{x} 37 %

73%

36% 1

Pa 22 Pa

0 25 50 75 100

70%

%

+/- -5 % 50 s

\bar{x} 37 %

73%

36% 1

4:56s

Pa 22 Pa

Graphic view of the current ventilation.

Current central ventilation.

Ventilation correction by xxx% in xxx seconds.

Average ventilation in the rooms

Optimum valve position in the room

Highest valve position xxx% in room xx

Restart measuring fans in the rooms.

Pressure in central duct.

CENTRAL ALARM



Alarm : 003 (Central vent. 1)

3.1.2.1



000 Pa
 100 Pa
 22 Pa



Central ventilation control alarm on/off

No data from climate controllers.

No ventilation (measurement = 0%).

Central ventilation pressure control alarm on/off (input R1)

Pressure sensor faulty.

Pressure too low.

Pressure too high.

000 Pa

100 Pa

22 Pa

Minimum central ventilation pressure control alarm limit.

Maximum central ventilation pressure control alarm limit.

Current pressure.

CENTRAL HEATING



Settings : 003 (Centr.heating 1)

3.2.1.1

76 %

05.0 °C

75.3 °C

75.5 °C

2

76 %

- Central heating status (heating is: "On").
- Current heating capacity of central heating ("controlled heating")

05.0 °C Minimum heat request (frost protection). If the temperature in the rooms (which pass on their heat request to this central heating boiler) falls to below the minimum heat request setting, the central heating boiler will switch on.

75.3 °C Current water temperature

75,5 °C Calculated water temperature



2

Room with the highest heat request.



Alarm : 003 (Centr.heating 1)

3.2.2.1



Central heating alarm on.

No data from KLD-100 controllers.

Water temperature sensor faulty.




Central heating alarm off.

CENTRAL INLET FLAP



Settings : 003 (Centr. Inlet 1)

3.3.1.1



The flap controls on the basis of ventilation. Normally, the opening of the flap is directly proportional to the flap position as a %. The air displacement caused by this flap, however, is not directly proportional to the flap position. The characteristic can be used to obtain a better flap position/air displacement ratio.

64 %

Current ventilation

64 %

Current valve position

ALARM



Alarm : 003 (Centr. Inlet 1)

3.3.2.1



Central flap control alarm on.

No data from KLD-100 controllers.



Central flap control alarm off.

📍 PRESSURE MEASUREMENT



Settings : 003 (Air wascher 1)

3.4.1.1



25 Pa



25 Pa

Current pressure (R2)

ALARM



Alarm : 003 (Air wascher 1)

3.4.2.1



010 Pa



100 Pa



25 Pa



Pressure measurement alarm on.



Pressure sensor faulty.



Pressure too low.



Pressure too high.



Pressure measurement alarm off.



010 Pa

Minimum central ventilation pressure control alarm limit.



100 Pa

Maximum central ventilation pressure control alarm limit.



25 Pa

Current pressure.

ALARM HISTORY



Latest alarms house			4.1.2
Alarm 0	1-1-2001	0:00	
Alarm code	No alarm		
Alarm 1	1-1-2001	0:00	
Alarm code	No alarm		
Alarm 2	1-1-2001	0:00	
Alarm code	No alarm		
Alarm 3	1-1-2001	0:00	
Alarm code	No alarm		

The latest 5 alarm causes which caused the alarm relay to de-energize are shown. The dates and times of the alarms are listed in addition to their causes.

Alarm 0: Shows the cause of the *most recent alarm*. The time until which the last alarm was (is) active is also indicated.

COMMUNICATION ALARM



Communication		4.1.3
Alarm	<input checked="" type="checkbox"/>	
Device address	<input type="text" value="0"/>	
Alarm status	No alarm	



System		5
Package	xxx_xx.xx.x_xx_x.x.x.xxxx.zip	
RTCPU		
Type	167	
Software version	x.xx.x	
Software date	xx-xx-xxxx	
WEC board		
Software version	x.x.x.xxxx	
BootApp version	x.x.x.xxxx	
Operating system version	x.xx	
Touch firmware version	xx_Tx	

- Package** : This shows the package number of the compressed software files.
- RTCPU**
 - Type : Device type number (167 = KL-6500).
 - Program version : Program version number of the embedded software (RTCPU processor PCB).
 - Program date : Program date of the embedded software
- WEC board**
 - Program version : Program version number of the WEC board software (GuiApp).
 - BootApp version : Program version number of the BootApp software.
 - Control system version : Program version number of the GuiApp operating software.
 - Touch firmware version : Program version number of the touch firmware software.

DEVICE



Device		5.1
Name	<input type="text" value="KL-6500"/>	
ENG, NLD, DEU, FRA, RUS	English <input type="button" value="v"/>	
POL, HUN, SPA, CES, TUR		
ZHO, JPN		
Brightness		
on	<input type="text" value="100"/> %	
off	<input type="text" value="015"/> %	
On-time	<input type="text" value="300"/> s	

Change the device name, the language shown and other features.

BRIGHTNESS

- on** : Background lighting brightness as a percentage during the "On time".
- Off** : Background lighting brightness as a percentage after the "On time" has elapsed.
- On-time** : Number of seconds during which the screen is lit with the "Brightness" "On" percentage after the last time a key was pressed.

Set 0 seconds: the light does not switch off, the "On time" for the "Remote control" is set to 300 seconds.

DATE AND TIME



Date/Time	5.1.1
Date	XX-XX-XXXX
Time	XX:XX
Beginning new day	XX h

Set the date and time, and "Beginning new day".

REMOTE CONTROL

Stienen BE does not accept any responsibility for any damage or loss when the "Remote control" is used. You have to ensure that there is a secure LAN environment, protected by a firewall.

If the installer has activated "Remote control", the menu will feature the  option.




Remote control	5.1.5.2
Disclaimer	
Manufacturer accepts no responsibility for damage when using Remote Control. You need to provide a secure LAN environment shielded from the internet through a firewall.	
Remote control	<input checked="" type="checkbox"/>
User	****
Access code	****
IPv4 Address	-----


If the KL-6500 is connected to a network, an IP address (IPv4 address) will automatically be assigned to the controller after you have entered the codes. You need this IP address in order to connect to the device through the browser.

1. Set the "Remote control" slider to the  position.
2. Enter a user code (the code must not be 0000).
3. Enter an access code (the code must not be 0000).
4. Write down the IP address.

LOGIN




- Open the Internet browser.
- Enter the IP address in the address bar and press ENTER.
- Press the TAB key.
- Enter the username and press the TAB key.
- Enter the password and press the TAB key.
- Press the ENTER key ("Login").



- The  symbol is shown at the top of the status bar to indicate that the device is operated remotely.
- If the device is operated locally, the remote connection is deactivated and you can only remotely see what is being changed, the coloured  symbol will change to a grey  symbol.
- If the device is operated locally (grey  symbol) and you mouse-click on one of the fields (keys), the system will log out automatically; you will have to log in again then.

The input fields and symbols can only be accessed by using your mouse (not by means of the keyboard).

AUTOMATIC LOGOUT



If there is no action during the "On time" (5 minutes by default), the device will automatically log off when the "On time" has elapsed.

Whenever an action takes place, the timer is filled with the "On time" again.

MAINTENANCE AND INSPECTION

Regular maintenance and inspection of the equipment are essential for its proper operation.

- **Do not forget to clean the ventilation system when cleaning the animal house.**
To minimise the energy consumption, it is important that the fans are clean. This also applies to the flaps, measuring fans and the ventilation pipe. Dust and dirt may affect the operation of the equipment. You can use a brush to clean the fans and tubes. Use a moist cloth to clean the climate control, the measuring fan impeller and the flaps. Never use a pressure cleaner to clean the climate control, the measuring fan impeller, flaps and other electrical equipment.
- **Check the underpressure in the house at regular intervals.**
Clogged up filters, air inlet flaps which are still in "winter mode", etc. may cause an unnoticed increase in the counter-pressure in the ventilation system in combination with rising temperatures. This will result in the fans having to work much harder than is usually required. When opening or closing the doors to the house, be alert to any resistance which you may feel. If you can feel the underpressure, you should check that the filters and flaps work properly.
- **Check the house for air leakage.**
Air leaks can lead to draughts and - in summer - they can result in unwanted heating due to hot air being drawn in from between the roof and the insulating materials for example. This will require the fans to work extra hard to enable the pre-set house temperature to be reached, causing the energy costs to increase unnecessarily.
- **Check the measuring fans**
The measuring fan operation will become less smooth due to wear.. The result is that the ventilation rate will increase while the fan speed stays the same! Have the measuring fans checked by an expert in good time.
- **Check the measured values and settings**
Since the climate control does what the sensors indicate, you should check the values measured by the sensors at regular intervals (e.g. whenever you have cleaned the animal house). We recommend having an expert check all settings and measured values at least once a year.
- **Fan**
Switch on all fans briefly, at least once a week, even in winter, to prevent the fans from getting stuck.
- **Alarm system**
Check the operation of the alarm system at regular intervals, e.g. once a month.
- **Temperature sensors**
Clean the temperature sensors every month.
- **Ventilation**
Clean the ventilation tubes at least once a year.

Good climate control is crucial for good business operations. Disease prevention starts with an optimum climate in the house. **Regular inspection of the fans and the climate controls is necessary.**